

## Radio Devices for Use in Hazardous Locations

### Guide Information

**Updated 11/10/2000**

Motorola INC.

1500 Gateway BLVD

Boynton Beach, FL 33426 U.S.A.

#### **Class I, Division 1, Groups A, B, C and D; Class II, Division 1, Groups E, F and G**

**Director II** paging receiver, Models A01, A03, or A04 followed by XKC, followed by 2, followed by 4, followed by 6, followed by 8, followed by A, followed by A or C: **Minitor II** paging receiver, Models H or Z followed by 01, 03, or 04, followed by UMC, followed by 1 or 3, followed by 1 or 2, followed by 1 or 2, followed by 2, followed by A, followed by A or C for use with two self-contained 1.5 V alkaline batteries.

**Director II SV** paging receiver, Models A03 or A04 followed by ZVC, followed by 2, followed by 4, followed by 6, followed by 8, followed by A, followed by A or C: **Minitor II SV** paging receiver, Model H03 or H04, followed by ZVC, followed by 1, followed by 2, followed by 2, followed by A, followed by A or C, for use with two self-contained 1.5 V alkaline batteries.

#### **Class 1, Division 1 Groups A, B, C and D; Class II, Division 2, Groups F and G**

**Bravo** paging receivers for use with a self-contained 1.5 V "AA" alkaline battery, Models A01, A03, A04, A05, followed by HQ or JR, followed by B or C, followed by 4 or 5, followed by 3, 6, or 9, followed by 61, followed by A, B, C or D, followed by A.

**Bravo** paging receiver with alphanumeric display for use with a self-contained 1.5 V, "AA" alkaline battery, Models A01, A03, A04, A05, followed by QA, followed by B or C followed by 4 or 5, followed by 6 or 9, followed by 62, followed by A, B C or D followed by A.

**Bravo** paging receiver with tone/silent alert only for use with a self-contained 1.5 V "AAA" alkaline battery, Models A01, A03, A04, A05, followed by AR, followed by B or C, followed by 4 or 5, followed by 3, 5, 6 or 9, followed by 68, followed by A, B, C, followed by A.

**Keynote** paging receiver for use with a self-contained 1.5 V "AA" alkaline battery, Models A01, A03, A04, A05, followed by CJ, EB or UP, followed by B or C, followed by 2, 7, 8 or 9, followed by 4, 5 or 6, followed by 0 or 6, followed by 1, 8 or 9, followed by AA.

**Bravo Express** paging receiver for use with a self-contained 1.5 V "AAA" alkaline battery, Models A01, A03, A04, A05, followed by NK, followed by B or C, followed by 4 or 5, followed by 1, 3, or 9, followed by 1 or 6, followed by 1, followed by A or B, followed by A.

**Memo Express** paging receivers for use with a self-contained 1.5 V "AAA" alkaline battery, Models A01, A03, A04, A05 followed by PH, followed by B or C, followed by 4 or 5, followed by 1, 3 or 9, followed by 1, 5 or 6, followed by 2 or 5, followed by A, followed by A.

**Ultra Express and Ultra Express FLX** paging receiver for use with a self-contained 1.5 V, "AAA" alkaline battery, Models A03, A04, A05 followed by HN, followed by B or C, followed by 4 or 5, followed by 8 or 9, followed by 6, followed by 1, followed by A or B, followed by A.

**Bravo Plus** paging receiver for use with a self-contained 1.5 V “AA” alkaline abattery, Models A03, A04, A05, followed by BP, followed by B or C, followed by 4 or 5, followed by 1, 3 or 9, followed by 1, 6 or 9, followed by 1, followed by A, B or C, followed by A.

**Bravo Lifestyle Plus** paging receiver for use with self-contained 1.5 V “AA” alkaline battery, Models A03, A04, A05 followed by VT, followed by B or C, followed by 4 or 5, followed by 1, 3 or 9, followed by 1, 6, or 9 followed by 1, followed by A followed by A.

**Bravo Classic** paging receiver for use with self-contained 1.5 V “AA” alkaline battery, Models A03, A04, A05, followed by GV, followed by B or C, followed by 4 or 5, followed by 1, 3 or 9, followed by 1, 6 or 9 followed by 1, followed by A, followed by A.

**Advisor** paging receiver for use with a self-contained 1.5 V “AAA” alkaline battery, Models A03, A04, A05, followed by AZ, KL, SC, TQ or WH, followed by B or C followed by 4 or 5, followed by 1, 3, 6 or 9, followed by 05, 10, 12, 62, 66, 69, 72, 73, 75 or 76, followed by A, B, C, D or E, followed by A.

**News Stream** paging receiver for use with a self-contained 1.5 V “AA” alkaline battery, Models A03, A04, A05, followed by KQ, followed by B or C, followed by 4, followed by 3 or 9, followed by 73, followed by A or B, followed by A.

**Bravo Encore** paging receiver for use with self-contained 1.5 V “AAA” alkaline battery, Models A03, A04, or A05 followed by LW, followed by B or C, followed by 4 or 5, followed by 8 or 9, followed by 6, followed by 1, followed by A, followed by A.

**Bravo Pro Encore** paging receiver for use with self-contained 1.5 V, “AAA” alkaline battery, Model A03 or A05, followed by TW, followed by B or C, followed by 4 or 5, followed by 8, followed by 1 or 6, followed by 1 or 4, followed by A, followed by A.

**Advisor Pro (Scriptor LX2), Advisor Pro FLX (Scriptor FLX2 ans Scriptor FLX2 Plus), Linguist** paging receivers for use with self-contained 1.5 V, “AAA” alkaline battery, Models A03, A04 or A05 followed by EJ, QU or YE, followed by B or C, followed by 4 or 5, followed by 8 or 9, followed by 10, 23, 24, 26, 62, 69, 72, 73, 75, 76, 77, 80, 81, 82 or 92, followed by A, B or C, followed by A.

**Bravo LX and Bravo FLX** paging receivers for use with self-contained 1.5 V, "AAA" alkaline battery, Model A03, A04 or A05 followed by MV, followed by B or C, followed by 4 or 5, followed by 8 or 9, followed by 6, followed by 1, followed by A or B, followed by A.

**Advisor Gold (Advisor LX32), Advisor Gold FLX (Advisor FLX32), and Scriptor ELX4** paging receivers for use with self-contained 1.5 V, "AA" alkaline battery, Models A03, A04 or A05 followed by DY, QW, RZ, UW, VH or WM, followed by B or C, followed by 4 or 5,

followed by 8, 9 or E, followed by 10, 62, 69, 72, 73, 75, 76, 77, 80, 82, 92 or 93, followed by A, followed by A.

**Gold Line** paging receiver for use with self-contained 1.5 V, "AAA" alkaline battery, Model A05 followed by LZ, followed by B or C, followed by 4 or 5, followed by 9, followed by 6, followed by 1, followed by A, followed by A.

**Pronto and Pronto FLX** paging receivers for use with self-contained 1.5 V, "AAA" alkaline battery, Model A03, A04 or A05 followed by UY, followed by B, followed by 5, followed by 8 or 9, followed by 6, followed by 1, followed by A followed by A.

**Wordline, Wordline FLX, Memo Express II, Memo Elite FLX** paging receivers for use with self-contained 1.5 V, "AAA" alkaline battery, Model A03, A04 or A05 followed by AA or EQ, followed by B or C, followed by 4 or 5, followed by 8 or 9, followed by 1, followed by 2, followed by A, followed by A.

3 OF 5

**Express XTRA and Express FLX** paging receivers for use with self-contained 1.5V, "AAA" alkaline battery, Model A03, A04 or A05 followed by HH or YZ, followed by B or C, followed by 4 or 5, followed by 8 or 9, followed by 1, followed by 1, followed by A, followed by A.

**Digitz** paging receivers for use with a self-contained 1.5V, "AAA", alkaline battery, Models A03 and A05 followed by AU, followed by B, followed by 5, followed by 8, followed by 1, followed by 1, followed by A, followed by A.

**MemoJazz and Jazz** paging receivers, for use with one self-contained 1.5 V, "AAA" alkaline battery. Models A03, A05 followed by BE or KY, followed by B, followed by 5, followed by 8, followed by 0 or 1, followed by 2 or 9, followed by A, followed by A.

**Advisor Elite** paging receivers for use with one self-contained 1.5 V, "AA" alkaline battery, Models A03, A05 followed by CM, followed by B, followed by 5, followed by 8, followed by 1, followed by 2, followed by A, followed by A.

**MegaPro 800 and CP1250 / Advisor Graphix** paging receivers for use with a self-contained 1.5 V, "AAA" alkaline battery, Models A03, A05 followed by AH, FV, GH, DK followed by B, followed by 4 or 5, followed by 8, followed by 1, 6, 7 or 8, followed by 0, 2, 3, 5, 6 or 9, followed by A or B, followed by A.

**LS750** paging receiver for use with one self-contained 1.5 V, "AAA" alkaline battery, Models A03, A04, A05 followed by ER, followed by B, followed by 5, followed by 8 or 9, followed by 1, followed by 1, followed by A, followed by A.

**Scriptor Jazz** paging receivers for use with a self-contained 1.5V, "AAA" alkaline battery, Model A03 followed by FB, followed by B, followed by 5, followed by 8, followed by 10, 23, 24, 41, 42, 62, 69, 72, 75, 76, 81, 82, 87, or 88, followed by A, followed by A.

**Scriptor FLX4** paging receivers for use with self-contained 1.5 V, "AA" alkaline battery, Model A03, followed by FY, followed by B, followed by 5, followed by 8, followed by 6, followed by 2, followed by A, followed by A.

**LS350** paging receivers for use with a self-contained 1.5 V, “AAA” alkaline battery, Models A03, A04, A05 followed by ES, followed by B, followed by 5, followed by 8 or 9, followed by 1, followed by 1, followed by A, followed by A.

**BR850** paging receivers for use with a self-contained 1.5 V, “AAA” alkaline battery, Models A03, A05 followed by BZ, PY followed by B, followed by 5, followed by 8, followed by 1, followed by 1, followed by A, followed by A.

**LS550** paging receivers for use with self-contained 1.5 V, “AAA” alkaline battery, Models A03, A05 followed by CP, followed by B, followed by 5, followed by 8, followed by 1, followed by 1, followed by A, followed by A.

**Satellite Series 9501 and Iridium SP-66K** paging receivers for use with self-contained 1.5 V, “AA” alkaline battery, paging receiver, Models A09, followed by WRB, CTB, followed by 5, followed by S, followed by 12, followed by AA.

**Class I, Division 1, Groups C, D; Class II, Division 1, Groups E, F, and G; Class I, Divisions 2, Groups A, B, C and D**

**Director II** paging receiver, Models A01, A03, or A04, followed by XKC, followed by 2, followed by 4, followed by 6, followed by 8, followed by A, followed by A or C.

4 OF 5

**Minitor II** paging receiver, Model H or Z, followed by 01, 03 or 04, followed by UMC, followed by 1 or 3, followed by 1 or 2, followed by 1 or 2, followed by 2, followed by A, followed by A or C for use with self-contained 2.6 V, rechargeable nickel-cadmium battery or two 1.5 V, alkaline batteries.

**Director II SV** paging receiver Models A03 or A04 followed by ZVC, followed by 2, followed by 4, followed by 6, followed by 8, followed by A, followed by A or C.

**Minitor II SV** paging receiver, Models H03 or H04 followed by ZVC, followed by 1, followed by 2, followed by 2, followed by 2, followed by A, followed by A or C for use with a self-contained 2.6 V, rechargeable nickel-cadmium battery or two 1.5 V, alkaline batteries.

**Class I, Division 1, Groups C and D; Class I, Divisions 2, Groups A, B, C and D; Class II, Division 2, Groups F and G**

**Keynote** paging receiver for use with a self-contained 1.5 V, alkaline or 1.3 V, nickel-cadmium “AA” battery, Models A01, A03, A04, A05, followed by CJ, EB or UP, followed by B or C, followed by 2, 7, 8 or 9, followed by 4, 5 or 6, followed by 0 or 6, followed by 1, 8 or 9, followed by A, followed by A or C.

**Class I, Division 2, Groups A,B, C and D; Class II, Division 2, Groups F and G**

**Renegade/Instinct** paging receivers for use with two 1.5V, "AAA" alkaline batteries, Models A03, A04, A05 followed by HJ, followed by B or C, followed by 5, followed by 9, followed by 6, followed by 1, followed by A, followed by A.

**Tango** two-way paging receivers for use with a self-contained 1.5V, "AAA" alkaline battery, Models A06 followed by UB or XZ followed by B, followed by 5, followed by 8, followed by 06, followed by A, B or C, followed by A.

**Sitemate/Courtesy Call** paging receivers for use with two 1.5V, “AAA” alkaline batteries, Model A04 followed by ZK or ZM, followed by C, followed by 1, 2 or 3, followed by 7, followed by 6, followed by 8, followed by A or B, followed by A.

**Minitor III** paging receivers for use with two “AAA” alkaline batteries, Model A01, A03, A04 followed by YM, followed by S, followed by 9, followed by 2, followed by 38 or 39, followed by A or B, followed by A.

**SP1300** paging receiver for use with two “AAA” alkaline batteries, Model A05 followed by CM, followed by B, followed by 5, followed by 8, followed by 12, followed by A followed by A.

**PF1500** two way paging receivers for use with one self-contained 1.5V, “AA” alkaline battery. Model A06 followed by CQ or FX, followed by B, followed by 5, followed by 8, followed by 6 or 12, followed by A, followed by A.

**PageFinder** two-way paging receivers for use with self-contained 1.5V, “AA” alkaline battery, Model A06 followed by AT or BT, followed by B, followed by 5, followed by 8, followed by 06, followed by A, followed by A.

**LS950** voice paging receivers for use with a self-contained 1.5V, “AA” alkaline battery and one self contained 3.0V lithium battery Part No. DLCR2 manufactured by Duracell or CR2 manufactured by Panasonic, Model A06 followed by GF, followed by S, followed by 9, followed by 8, followed by 5, followed by 0, followed by A, Followed by A.

**Talkabout T900** two way paging receiver for use with one self-contained 1.5V, “AA” alkaline battery, Model A06 followed by JE or PK, followed by B, followed by 5, followed by 8, followed by 06, followed by A, followed by A.

5 OF 5

**Tenor** two-way paging receivers for use with self-contained 9V alkaline battery, Model A06 followed by QN, followed by S, followed by 9, followed by 8, followed by 43, 50 or 59 followed by A or B, followed by A.

**Class I, Division 2, Groups C and D: Class II, Division 2, Groups F and G.**

**PageWriter P935, PageWriter 2000, PageWriter 2000X, PageWriter 2000X R25** two way paging receivers for use with Motorola 3.6 V nickel metal hydride battery pack, part no. PTNN4005A. Model A06 followed by AX, ET or ZG, followed by B, followed by 5, followed by 8, followed by 06, followed by A, followed by J.

**Minitor III** paging receivers for use with two “AAA” Nickle Cadmium rechargeable batteries, Models A01, A03, A04 followed by YM, followed by S, followed by 7 or 9, followed by 2, followed by 38 or 39, followed by A or B, followed by C.

